



### Step One

Position the GutterRx™ panel over gutter, resting the back of the panel against the drip edge/fascia board and snapping the front edge of the panel into the front of the gutter. Make sure the panels are level.

### Step Two

Zip screw front edge of GutterRx™ panel to top of gutter lip using pre-set fastening points. Take care not to over-tighten the screw.

### Step Three

Zip screw back edge of GutterRx™ panel to the drip edge/fascia board using the pre-set fastening points.

### Step Four (OUTSIDE CORNERS)

Cut first panel on 45° angle. Cut second panel of GutterRx™ on 45° angle as well, leaving a slight overlap through which you can secure the mitered panels together.

### Step Five (INSIDE CORNERS)

Run your first panel of GutterRx™ to the back of the gutter completely covering the inside miter portion of the gutter. Trim out appropriate portion of the front lip of the next panel so that it can overlap first panel. Zip screw two overlapping sections together. When necessary, fashion small splash guard on top of the overlapping sections.